# Visual Guide to Home Fire Safety





#### In an emergency



If you have an emergency phone Triple Zero (000).



If you are deaf, hard of hearing or have a speech impairment, you can contact emergency services through the National Relay Service.

SMS relay: 0423 677 767 ask for 000
Chat: nrschat.nrscall.gov.au
Captions: nrscaptions.nrscall.gov.au
Video relay: skype NRS ask for 000

TTY: dial 106

Learn more: accesshub.gov.au/about-the-nrs/how-to-make-an-emergency-call-using-the-nrs







#### What to do in a fire

Make sure you can get out of your house if there is a fire.



If there is a fire in your house, crawl low and get out.




Get out and stay out.

Never go back inside!

#### **Smoke alarms**








Test your smoke alarm monthly.


Vacuum and dust alarms every six (6) months.

If your smoke alarm has a battery, change it once a year.


- For hard wired smoke alarms change your back-up battery once a year.
  - Check the expiry date of your lithium battery smoke alarm every year.



## Fire safety



Keep lighters and matches away from children.



Cool a burn under gentle cool running water.

## Escape plan



## Make a plan in case of fire



Recommended Smoke Alarm locations.




Smoke Alarm locations required by law.



Carbon Monoxide Alarms, recommended for homes using:

- gas for cooking or heating
- wood or pellet fires.



Go to your Safe Meeting Place e.g. letterbox.

## Cooking



Stay with cooking.



Never leave cooking.

## Cooking



Do not use portable stoves inside.




Only use gas cookers and gas bottles outside.

## Cooking




Do not store or use gas bottles inside.




Store gas bottles outside.

#### **Fires and heaters**





Keep everything 2 metres from the heater. That's at least 2 big steps.



Protect fires with a guard and never leave the door open.

## **Electricity**





## **Electricity**



Turn off electrical items at the power point.




Check electric blankets and turn them off when going to bed.

## **Electricity**



Blocked or full lint filters can cause dryers to overheat and start fires.




Always let a dryer finish its full cycle.




Clean lint from the filter.




Dispose of the lint properly.



Do not charge phones, laptops and other devices on beds, couches or under pillows.




Charge devices on a hard surface away from things that might catch on fire.




Unplug a charger when the battery is fully charged (100%).




Do not leave batteries charging overnight or when you are not home.



Do not charge e-bikes, e-scooters, and mobility devices inside the house.



Charge e-bikes, e-scooters and mobility devices undercover outside where possible.



Always use the charger that came with the battery or device. If you need to replace the charger, seek advice.



Have a working smoke alarm in places where batteries are charged and stored, such as garages or sheds.

## **Smoking**

Ensure cigarette butts are out.



Do not smoke in bed.



## **Candles and incense**







To contact the Migrant Resource Centre Tasmania:

Phone **03 6221 0999** 

Email reception@mrctas.org.au www.mrctas.org.au





Learn more at: www.fire.tas.gov.au

Free-call 1800 000 699









